

SHEAFFER'S
Threesome



*for your every
writing need!*



on

SHEAFFER'S
WRITING INSTRUMENTS

The Right Way to Fill your *Plunger* type *Sheaffer pen*

UNSCREW CAP—

at top of barrel and pull plunger out full distance (in case of desk pens, unscrew quill); hold point within wide mouth of SKRIP bottle.

IMMERSE—

entire point in SKRIP. work plunger up and down several times. This cleans the pen and moistens the fissures in the fluid control.

THE PEN FILLS—

on the down stroke

For flushing purposes, pump plunger several times. On final down stroke allow point to remain in SKRIP for ten seconds; tighten plunger cap or quill; wipe point clean with cloth or tissue.



NOTE: Changing weather conditions may cause water to appear in droplets on the point. Do not confuse this condensation with leakage; simply wipe it off!

IMPORTANT Do not attempt to repair or transfer gold points and assemblies. Always send your pen to the factory or to a Sheaffer dealer for repairs.

to Fill your *Lever type pen*



Immerse the gold point in SKRIP; open and close the lever; for flushing purposes open and close lever several times; allow point to remain in SKRIP for ten seconds; remove and wipe point clean with cloth or tissue.

to Reload your *Fineline pencil*

Turn the top of pencil to right until small metal push rod projects slightly; then turn all the way back to left; insert lead as far as it will go and press its point gently against any hard surface to engage clutching mechanism.

How to Get the Best Results with Sheaffer's *Stratowriter*

RETRACTABLE POINT AND CAP MODELS

KEEP TIP DRY

Treat the Stratowriter as you would a conventional fountain pen—it is not a pencil . . . the pressured system of ink feed—the only positive means for continuous, even writing—may force a slight accumulation of ink at the ball point. Wipe it off occasionally.

INSERT WRITING END CAREFULLY


When inserting writing end into cap, line the two parts up and insert carefully. Otherwise, writing tip may touch inside walls of cap, leaving small amount of fluid on gripping surface.

TO REMOVE UNIT... FROM CAP MODEL

for replacement, unscrew barrel from complete writing unit just above the metal thread ring. Then unscrew writing unit from writing section.

TO REMOVE UNIT FROM RETRACTABLE POINT MODEL

Unscrew the two-part barrel while writing tip is retracted. Grasp the upper part of the barrel above the clip so as not to bend the clip—remove writing unit and replace with a new writing unit.



Some Cautions for *Best Results*

Retract the point before returning to pocket—treat as you would an ink-filled fountain pen to avoid smudges on your fingers or clothing which would be transferred from the ball point if handled carelessly.

Do not carry your Stratowriter in a shallow shirt pocket or any other place where lint may come in contact with the writing tip. Any soft material will absorb Strato-Ink like a wick, and it will stain the material.

If, by any chance, you do get stains on your fingers, remove with alcohol, as alcohol is a solvent for Strato-Ink.

The Stratowriter ball point is set in its socket to extreme pressure limits. It will withstand all ordinary writing pressures, but do not tap or drop it on the floor or any hard surface; otherwise the tip may be damaged.

Guarantee on SHEAFFER'S *Writing Instruments*

All Sheaffer writing instruments are made of fine materials by fine craftsmen. Sheaffer guarantees to replace defective parts without charge.

If your pen, pencil or Stratowriter needs attention, deliver it to any Sheaffer dealer.

SPECIAL USES

Stratowriter is especially effective for writing at extremely high or low temperatures, at great altitudes—for writing multiple carbons and on unusual surfaces, such as wood, and leather.

CUSTOM-BUILT GOLD POINTS

IN A VARIETY OF STYLES FOR EVERY WRITING REQUIRED—EVERY INDIVIDUAL NEED

Accountants

Shorthand

Extra Fine

Fine

Medium

Coarse

Stub

Broad Stub

Flexible Extra Fine

Left

Oblique Stub

Flexible Left

Oblique Stub

Flexible Stub

Flexible Fine

Flexible Medium

Flexible Coarse

MUSIC

Available on most TRIUMPH models. Black Color Only.

Slight Additional Cost.

THERE'S A POINT FOR EVERY STYLE OF WRITING

SHEAFFER'S "TRIUMPH"

STYLES, SIZES AND
COLORS FOR EVERY
HOME, OFFICE OR
STUDY REQUIREMENT.
NEW DESK SET CRE-
ATIONS BY SHEAFFER
WILL FLATTER ANY
SURROUNDINGS.

SEE THESE BEAUTI-
FUL DESK SETS TODAY
AT YOUR SHEAFFER
DEALER . . .

DESK SETS



JET CRYSTAL
SPANISH ONYX
MEXICAN ONYX
ITALIAN MARBLE

A DAILY HELPMATE FOR HOME, OFFICE AND STUDY

EFFICIENT—
INEXPENSIVE—
SAFEGUARD

RESERVOIR
DESK SET

SCIENTIFICALLY
CONSTRUCTED
PRACTICALLY
UNSPILLABLE
ALWAYS READY
TO WRITE



HOLDS A FULL BOTTLE OF SKRIP.
FOUNTAIN PEN ACTION. WRITES
PAGES WITHOUT REFILLING.

SHEAFFER'S
Skrip

MAKES ALL PENS
WRITE BETTER
MAKES YOUR
SHEAFFER
WRITE BEST

ALWAYS USE SHEAFFER'S

Fine Line Leads

IN YOUR MECHANICAL PENCIL