

3 STEPS IN FILLING YOUR *Finger tip* PEN

1.

Dip gold point in ink until holes in point are covered.

2.

Open and close lever three times. With lever closed and point immersed, count 10, and remove from ink.

3.

Wipe point section clean of all ink on outer surface.

Remember:

- A. It takes a new pen a few days to get "broken in."
- B. Flush pen occasionally with cold water, especially if changing brands of ink.

This Pen and Pencil have been engineered to give years of unequalled writing pleasure . . . years of complete writing ease. Both are fine, precision-made writing instruments embodying exclusive and practical mechanical improvements in fountain pen and mechanical pencil design.

MATCHING PENCIL. The Moore Pencil, matching the Fingertip Pen in gift sets, has *positive top action*. Hold

pencil vertically, press down the top, and a perfect point is expelled. Six months' supply of leads is provided, and the leads feed themselves automatically, one after another. When a new supply is needed, remove top, remove eraser cap, and fill chamber with any standard "Fine" lead. Replace eraser cap and top, hold vertically, and press top down three or four times.

*Since 1900, the great advancements in fountain pen design have been conceived and produced first by **MOORE**.*

Guarantee

This pen is fully guaranteed against defective parts or workmanship for the life of its original owner. If, for any reason, this pen requires service, return the complete pen to our factory. If no replacements for missing, broken or substitute parts are necessary, the only charge will be 35¢ to cover costs of postage, handling and insurance. When replacement parts are necessary, they will be charged for at list prices. When returning a pen for service, be sure to give name, address and complete instructions.

MOORE PEN COMPANY
29 Melcher Street, Boston, Mass.

FOR YOU WHO CHERISH FINE THINGS—YOUR...

MOORE *Fingertip* **PEN**
AND MATCHING PENCIL