

Moore Pen Co. 29 Melcher St., Boston, Mass.

HOW TO FILL THE MOORE FINGER TIP FOUNTAIN PEN

1. Dip nib in ink until hole or "heart" is covered.
2. Lift lever 2 or 3 times.
3. Close lever and count 10 before taking nib out of ink.
4. Wipe point section clean.

Remember: When changing brands of ink, be sure to flush pen perfectly clean with cold water before refilling.